


システムポール用部品

架空線引留バンド	φ102 B・I	UHB-102B.I
	φ115 B・I	UHB-115B.I




電力線引留バンド	φ140 B・I	UDB-140B.I
----------	----------	------------



通信線引留バンド	φ140 B・I	UCB-140B.I
----------	----------	------------




ボックス取付バンド(1個)	φ115 B・I	UBB-115B.I
---------------	----------	------------




片フックバンド	φ 60-Z	UKF-60
	φ 76-Z	UKF-76
	φ 90-Z	UKF-90
	φ102-Z	UKF-102
	φ115-Z	UKF-115
	φ140-Z	UKF-140




両フックバンド	φ 60-Z	URF-60
	φ 76-Z	URF-76
	φ 90-Z	URF-90
	φ102-Z	URF-102
	φ115-Z	URF-115
	φ140-Z	URF-140




メーター取付バンド両面(2個1組)	φ 90-Z	UMB-90R
	φ115-Z	UMB-115R




メーター取付バンド片面(2個1組)	φ 90-Z	UMB-90K
	φ115-Z	UMB-115K




固定バンド	φ 90-Z	M12	UKB-90
	φ102-Z		UKB-102
	φ115-Z		UKB-115
	φ127-Z	W1/2	UKB-127
	φ140-Z		UKB-140




足場ボルト	L=245 (φ90~115用) Z	USB-245L
	L=270 (φ140用) Z	USB-270L




補助足場ボルト(ナット付) L=140Z	USBN-140
----------------------	----------



両足場バンド φ140Z	URS-140
--------------	---------



TVアンテナ支持金具	φ 90用Z	UTV-90
	φ102用Z	UTV-102
	φ115用Z	UTV-115
	φ140用Z	UTV-140



BS (CS) アンテナ支持金具	φ102Z	UBS-102
	φ115Z	UBS-115



リングボルト	URB
--------	-----

